

1. PRODUCT SPECIFICATIONS & SIZE

Parameter	Dimension / Detail
Total Length	7.34 in (186.5 mm)
Max Width	2.46 in (62.5 mm)
Handle Diameter	1.25 in (32 mm)
Charging Interface	DC Magnetic USB Charging
Battery Life	Approx. 2 Hours (100% full)

2. FUNCTION & CONTROLS

The device features dual-button independent or synchronized control interfaces designed for intuitive handling.

Power & Gear Shifting Button (↻ / Power Icon)

- **ON / OFF:** Press and hold the power button for **3 seconds** to power the device on or off.
- **Vibration Modes:** Short press the button to switch between **9 distinct vibration modes**.

Intensity Control Button (– / Minus Icon)

- **Gear Control:** Long press the – button for **3 seconds** to control the product to increase or decrease gears.

ORIGINAL INSTRUCTION REFERENCE




Fig 1.0 — Official Quick Start Guide and Instruction layout for GODLIKE S681

- **Mode Switch:** Short press the – button to cycle through **9 vibration modes**.

3. USB MAGNETIC CHARGING GUIDE

Connect the magnetic DC charging cable to the port located at the base of the device. Compatible with standard 5V USB power outputs (Car charger, Wall adapter, PC USB port, Power Bank).

CRITICAL CHARGING WARNING

- * **WARNING:** Please **DO NOT** use adaptors with output exceeding **5V (>5V)**.
- * Please ensure your toy is **fully charged** prior to first-time use.

CHARGING BEST PRACTICES

- Connect the device to a standard USB port to charge.
- **Do not** use the device while charging.
- Ensure power adapter rating is strictly **below 5V**.
- Do not keep the product immersed in water for extended periods.
- If the device fails to respond immediately when connected, please wait for **10 minutes** to confirm initialization.

4. PRODUCT MAINTENANCE & CLEANING

CLEANING INSTRUCTIONS

- **Clean:** Wash thoroughly with warm water and antibacterial soap or specialized toy cleaner.
- **Wipe:** Dry the product carefully with a clean, lint-free cloth or towel.
- **Store:** Keep the product in a cool, dry, and clean place away from dust.

CLEANING ATTENTION

- Never clean this product with organic cleaners containing **alcohol, gasoline, or acetone**.
- Avoid exposure to direct sunlight and high temperatures.

5. SAFETY GUIDELINES & OPERATING PRECAUTIONS

SAFETY INSTRUCTIONS (MANDATORY COMPLIANCE)

- **Temperature Limit:** Do not use or expose the product at temperatures exceeding **167°F / 75°C**.
- **Discomfort:** Immediately stop using the product if any physical discomfort or irritation occurs.
- **Lubrication:** It is highly recommended to use the device with **water-based lubricants** only. Avoid silicone-based lubricants which may damage the material.
- **Inspection:** Do not use the product if you find any surface roughness, cracks, or structural damage.
- **Storage:** Keep out of reach of children and pets.

6. ENVIRONMENTAL & REGULATORY COMPLIANCE

This product complies with international safety and environmental standards including CE, UKCA, RoHS, and WEEE directives for electronic waste recycling. Please dispose of responsibly at designated collection facilities.