


CONDICE-S500

Comprehensive Electronic User Manual & Operation Guide (v2)



Embedded Official Product Instruction Sheet (CONDICE-S500 Quick Start Guide & Specifications)

1. Product Overview & Dimensions

The **CONDICE-S500** is an advanced dual-stimulation wellness device engineered with a tongue-licking mechanism, thrusting features, and multi-speed settings designed for Clitoris and G-Spot stimulation.

Specification Component	Dimension / Parameter	Description
Overall Length	7.99 in (203 mm)	Full body height / length
Base Width	3.11 in (79 mm)	Base structure width
Shaft / Head Width	1.41 in (36 mm)	Top stimulation tip width
Handle / Body Width	1.65 in (42 mm)	Ergonomic control grip width
Charging Time	Approx. 2 Hours	Full charge duration via magnetic USB

2. Operating Instructions (ON/OFF & Functions)

- **Tongue Licking Function:** Long-press the lower button for **3 seconds** to turn ON/OFF the tongue licking function.
- **Head Function (Thrusting/Vibration):** Long-press the upper/head button for **3 seconds** to turn ON/OFF the function on the head.

Switching Modes:

- **Vibration & Thrusting Mode:** After turning on, press the designated button to switch between **9 vibration & thrusting modes**.
- **Licking Mode:** After turning on, press the button to switch between **9 tongue-licking modes**.
- **Pause / Restart:** Double-click the button to pause or re-start the tongue-licking function.

 **Operational Note:** Familiarize yourself with the dual independent control buttons to customize simultaneous or separate functions.

3. USB Magnetic Charging & Power Guidelines

CRITICAL WARNING:

- Please **DO NOT** use a power adaptor with an output exceeding **>5V** to charge the device.
- Please make sure your toy is **fully charged before its first use**.

Charging Specifications:

- **Charging Connection:** Magnetic DC charging port.

- **Power Sources:** Compatible with standard USB ports, wall adapters, computers, and power banks (1000mAh+).
- **Indicator Guidelines:**
 -  **2H** charging duration for full cycle.
 -  **100%** indicator signifies fully charged status.
- **Important Usage Notes:**
 - Do not use the device while charging.
 - Can not keep in water for a long time.
 - If the product can't be charged when electrified, please wait for 10 minutes to confirm.

4. Product Cleaning & Maintenance

✨ **Hygiene Best Practices:** Proper maintenance ensures safety and longevity.

- **Clean:** Please clean the product with warm water or antibacterial soap after every use.
- **Wipe:** Dry the product with a clean cloth or towel.
- **Save:** Keep the product in a cool, dry, and clean place.
- **Attention:** **Never clean this product with organic cleaner that contains alcohol, gasoline, or acetone. Avoid direct sunshine.**

5. Safety Guidelines & Precautions

SAFETY MANDATES:

- Do not use it at temperature over **167°F / 75°C**.
- **Stop using it** when any discomfort occurs.
- It is recommended to use it with **water-based lubricant**.
- Do not use it if you find the product unsmooth or damaged.
- **Keep out of reach of children.**