

SEX LIPS — Model S595

Electronic User Manual & Operation Guide | Comprehensive Specifications, Safety Protocols, and Functional Instructions

1. Original Instruction Manual Image Reference

The official quick start guide and technical schematic provided for model S595 are displayed below in high resolution for visual reference:




Figure 1.1: Official Quick Start Guide, Charging Diagram, and Safety Instructions for SEX LIPS S595

2. Product Specifications & Overview

Product Name	SEX LIPS
Model Number	S595
Dimensions	Length: 5.19 in (132 mm) Width: 2.20 in (56 mm) Height: 2.32 in (59 mm)
Charging Method	USB Magnetic DC Charging (1.35H Full Charge Time, 100% Battery Indicator)

3. Operating Instructions & Button Control

Control Action	Operation Detail	Description & Functionality
Power ON / OFF	Hold ● button for 3 seconds	Turns the product on or off. Press firmly until vibration/LED feedback is received.
Vibration Modes	Press ● button briefly	Cycles sequentially through 9 distinct vibration modes .
Tongue Licking & Lip Mode	Press ● button briefly	Activates and cycles through 9-frequency tongue licking and lip opening/closing modes .

 **Quick Start Tip:** Please make sure your toy is fully charged before the first time of use. It takes approximately 1.35 hours to reach a 100% charge status.

4. USB Magnetic Charging Guidelines

Follow these essential power requirements to maintain battery longevity and ensure safe operation:

- Connect the magnetic DC cable securely to the device's charging port and plug into any standard USB port (Computer, Power Bank, Car Charger, or Wall Adaptor).
- Charging status is monitored via the LED indicator (approx. 1.35 hours for a complete full charge).
- If the product cannot be charged immediately when electrified, please wait for 10 minutes to confirm activation.

 CRITICAL CHARGING WARNING:

1. **DO NOT use adaptor with >5V output!** Only use standard 5V power sources (PC, Power Bank, 5V USB wall chargers). Exceeding 5V can damage the internal circuitry.
2. **DO NOT use the device while charging.** Always unplug the device before use.

5. Product Maintenance & Cleaning

Proper hygiene and maintenance ensure product durability and skin safety:

- **Cleaning:** Clean the product thoroughly after each use with warm water and antibacterial toy cleaner or mild soap.
- **Drying:** Wipe dry with a clean, lint-free cloth or microfiber towel.
- **Storage:** Keep the product in a cool, dry, and clean place away from direct sunlight.

 **Cleaning Caution:** Never clean this product with organic cleaners containing alcohol, gasoline, or acetone. Avoid direct exposure to strong sunlight. Note that while water-resistant, the device cannot be submerged or kept in water for a long time.

6. Safety Protocols & Usage Precautions

Category	Safety Requirement
Temperature Limit	Do not use at temperatures exceeding 167°F / 75°C .
Discomfort Stop	Stop using immediately when any discomfort or irritation occurs.
Lubrication	It is strongly recommended to use exclusively with water-based lubricants (silicone or oil-based lubes may degrade the silicone body).
Product Integrity	Do not use if you find the product unthought/unsmooth, cracked, or damaged in any way.
Child Safety	Keep out of reach of children. Adult novelty item only.

 **Environmental Compliance & Recycling:** This product carries CE, UKCA, and RoHS certifications, complying with international safety standards. In accordance with European WEEE directives (e.g., French Triman / recycling guidelines), please dispose of electronic components responsibly at designated collection points or recycling centers.