

SH D-X024 User Manual

Professional Multi-Functional Wellness Device • Operating Guide & Specifications




Figure 1: Original Product Schematic, Dimensions, Control Interface & Charging Instructions

1. Technical Specifications

Product Model	SH D-X024
Dimensions	8.77 in × 3.43 in × 1.45 in (223 × 87 × 37 mm)

Material Composition	Liquid Silicone Gel, ABS (Acrylonitrile-Butadiene-Styrene Copolymer)
Battery Capacity	900 mAh
Charging Voltage & Current	Input: 5 V Current: 550 mA (Max Rated Current: 1000 mA)
Charging Time	Approximately 180 minutes (3 hours)
Usage Time	Up to 61 minutes (varies depending on vibration frequency)
Water Resistance Rating	IPX7 (Waterproof)
Operating Noise	Low noise design under normal operating conditions

i Note on Specifications

All test data are recorded under standard operating conditions and may vary slightly depending on environmental factors and actual usage patterns.

2. Operation Declaration & Controls

The device features an intuitive 3-button control interface. Below are the detailed operating modes:

Vibration Mode

- **Power ON/OFF:** Long-press the **"Do Not"** button for 3 seconds.
- **Control:** After turning on the device, click the **"Product"** button to cycle through the 9-frequency vibration modes.

Beading Pattern

- **Power ON/OFF:** Hold down the **"Grass"** button for 3 seconds.
- **Control:** After turning on, tap the corresponding button to switch between 9-frequency bead rotation modes or change the rotation direction.

Sucking Pattern

- **Power ON/OFF:** Long-press the designated power button for 3 seconds.
- **Control:** After turning on, tap the **"Classic"** button to switch between 5 suction modes.

3. Product Charging Instructions

Optimal Charging Guidelines

- Before each charge, please clean and thoroughly dry this device.
- Connect the USB cable to a USB power adapter (*not included*) or a standard USB port. Charging can be performed using any compatible USB power adapter.
- When charging via a computer's USB port, the device will not charge if your computer enters sleep mode.
- A full charge takes approximately **3 hours**. Actual charging time may vary based on remaining battery level.
- Battery endurance lasts up to **61 minutes** on a full charge. Higher vibration frequencies consume battery power faster.

4. Important Safety & Maintenance Warnings

Critical Safety Warnings

- **Battery Protection:** Do NOT drain the battery completely before charging. To extend battery life and ensure optimal charging performance, we recommend recharging the device before vibration output significantly decreases.
- **Power Adapter Limit:** Always use a power adapter with a voltage **below 5 V**. Exceeding this limit may damage internal circuitry.
- **Water Resistance:** While rated IPX7, ensure the charging port is completely dry before connecting any power source.