

HOPSTAR PRO-027

Electronic User Manual & Comprehensive Operational Guide

PROFESSIONAL EDITION • IPX7 WATERPROOF • DUAL STIMULATION

1. Document Overview & Original Instruction Manual

The following reference image is the original factory specification and operational instruction guide for the **HOPSTAR PRO-027**. It has been embedded at high resolution below to ensure that all technical diagrams, dimensions, and operational icons remain completely legible.




Figure 1.1: Official factory instruction sheet showing parameters, dimensions, charging specs, controls, cleaning, and safety guidelines.

2. Technical Specifications

Detailed technical parameters and physical specifications of the HOPSTAR PRO-027 device:

SPECIFICATION PARAMETER	DETAIL / VALUE	NOTES & COMPLIANCE
	HOPSTAR PRO-027	High-end wellness device

SPECIFICATION PARAMETER	DETAIL / VALUE	NOTES & COMPLIANCE
Product Name & Model		
Material Composition	Solid Silicone + ABS	Body-safe, hypoallergenic, smooth finish
Dimensions	5.08" × 4.49" × 2.05" (129 mm × 114 mm × 52 mm)	Ergonomically engineered proportions
Functional Modes	8 Suction Levels + 11 Vibration Levels	Independent dual-motor control
Net Weight	207g	Balanced weight distribution
Waterproof Rating	IPX7 Waterproof	Fully submersible for easy cleaning
Power Source	USB Magnetic Charging	Convenient magnetic snap-on cable
Charging Time	2 Hours (2h)	Full charge indicator support
Working Time	Approx. 127 Minutes	High-capacity rechargeable battery

3. Operating Instructions & Control Guide

The HOPSTAR PRO-027 features intuitive tactile controls designed for seamless transitions between multiple intensity settings.

Suction Function Control

- **Power On/Off:** Press and hold the suction button for **3 seconds** to turn the device on or off.
- **Level Adjustment:** Press the button briefly to cycle through the **8 suction levels**.

Vibration Function Control

- **Power On/Off:** Press and hold the vibration button for **3 seconds** to turn the device on or off.
- **Level Adjustment:** Press the button briefly to cycle through the **11 vibration levels**.

4. USB Magnetic Charging Guide

Proper charging ensures battery longevity and safe operation. Follow these guidelines carefully:

- **Port Preparation:** Before charging, make sure the DC charging port is completely **dry and tidy**.
- **Connection:** Connect the magnetic charging cable to the charging contact points located at the bottom of the product.
- **Indicator Light Status:**
 - *Flashing light:* Device is currently charging.
 - *Solid light:* Device is **fully charged**.

CRITICAL SAFETY WARNING — CHARGING:

- **Do not use the product while charging.**
- Recommend using the original charging cable and a power adapter rated at **5V or less**.

5. Product Maintenance & Cleaning

Maintaining hygiene is essential for product longevity and skin health.

- **Cleaning:** After using, please clean it with neutral soap/detergent and warm water.
- **Storage:** Store in a cool, dry place away from direct sunlight.
- **Inspection:** Perform periodic inspections for any signs of physical damage or wear.

MAINTENANCE TIP:

- Keep away from children and minors at all times.
- Inspect the silicone casing regularly for tears or surface degradation. Stop using immediately if damaged.

6. Important Safety Precautions

Review all safety guidelines prior to initial operation:

- This product is an adult toy; minors are strictly prohibited from using it.
- During use, please do not use excessive force; please pay attention to avoid injury.
- Please do not borrow this product to others. If you feel uncomfortable when using, please stop immediately.

- In order to protect your delicate skin, we recommend using with water-based lubricants.

i REGULATORY & COMPLIANCE:

- Complies with UKCA, RoHS, CE, and 18+ age restrictions.
- Eco-friendly disposal: Please recycle in accordance with local regulations. Made in China.